

## **SHARKSKIN ULTRA SA™ - INSTALLATION INSTRUCTIONS**

**Note: Sharkskin Ultra SA™ (self-adhered) synthetic roof underlayment utilizes an aggressive synthetic adhesive. Keep away from hair, face, and clothing.**

1. Cut a 10-15 ft. piece of Sharkskin Ultra SA or shorter as application dictates. Longer pieces and or application of the full roll can be done once installations of shorter pieces are mastered.
2. Position Sharkskin Ultra SA underlayment over installation location. Do not pull release liner away during this process.
3. Staple across the top of the SA above the 2" lay line as needed to hold Sharkskin Ultra SA in position over installation location. Do not stand on Sharkskin Ultra SA while temporarily fastened.
4. Reach under Sharkskin Ultra SA underlayment to the middle of the sheet to split release liner. Slowly pull the release liner fold downward and away allowing the synthetic adhesive of Sharkskin Ultra SA to make contact with the roof sheathing/substrate/deck.
5. Continue pulling away release liner while using gloved hands, broom, or roller to press the Sharkskin Ultra SA down against the roof deck.
6. Apply the entire lower half of the Sharkskin Ultra SA underlayment, being sure Sharkskin Ultra SA is properly adhered to the roof deck.
7. Pull away the top half of the Sharkskin Ultra SA and remove staples. Remove the split release liner slowly and gradually as the upper half of the Sharkskin Ultra SA underlayment is pressed against the roof deck.
8. Continue pulling away release liner while using gloved hands, broom or roller to press the Sharkskin Ultra SA down against the roof deck.
9. Once full sheet of Sharkskin Ultra SA is installed, use heavy roller at all horizontal and vertical laps.
10. BE CAREFUL TO OBSERVE SAFE ROOFING CODES AND PRACTICES (OSHA). USE CAUTION WHEN WALKING OR STANDING ON SHARKSKIN ULTRA SA. COEFFICIENT OF FRICTION MAY CHANGE WITH WET, DUSTY, OR ICY CONDITIONS. FAILURE TO USE PROPER SAFETY GEAR AND FOOTWEAR CAN RESULT IN SERIOUS INJURY.